



GENERAL INSTRUCTIONS

To Operate the Sno-King

1. Load hopper with Ice.
2. Close pusher cap, and apply gentle downward pressure.
3. Turn on the power switch.
4. Press and hold in the momentary switch. Release the button once all of the ice has been shaved.
5. Do not lift the pusher cap until the motor is off and the shaver head has stopped.

NOTE: Never allow any foreign or metallic objects around the shaver area of the *Sno-King*. Ice picks, scoops, and debris that may be in the ice often damage blades.

Ice Requirements

The *Sno-King* can take ice cubes or block ice, if you break the block into pieces approximately 2 to 3 inches in size.

NOTE: The ice will not enter the shaving chute if the pieces are too large.

Daily: Cleaning the Ice Shaver

1. Wipe the outside parts with a clean cloth.
DO NOT use oven cleaners, as they will damage parts of the machine.
2. Ammonia cleaners will damage the Lexan Windows. Use only non-ammonia cleaners, such as **Gold Medal®** Watchdog Glass Cleaner (item number 2588).